

Safety and Assembly Instructions

U-Stand



Weight Capacity: 100KGS

*(Though if the swing/chair capacity is lower,
then you follow that limit instead)*

We hope you enjoy this U-stand, matched with suitable chair or swing.




OR



Please either position the stand with the back against a wall, or with sandbags. It's a precaution against too strong swinging, since this stand is only for sitting or gentle swinging.


Stand Diagram



Assembling your stand



1. Remove the tubes and accessories from the carton.



2. Refer to the stand diagram (previous page) before proceeding.



3. You'll find that the pieces are numbered to match the instructions diagram.



4. Connect all of the metal pieces, and bolt them together.



5. Attach and tighten the eye bolt to the top. Attach a carabiner to the eye bolt. If you want to rotate the swing by 90 degrees, then add a 2nd carabiner below the 1st one. If you want to lower the swing further, then you can add a chain between the carabiners (chain not included).



6. Attach your suitable swing of choice to the carabiner.

Safety instructions

Most importantly: Please either position the stand with the back against a wall, or with sandbags, as mentioned on the first page with pictures. It's a precaution against too strong swinging, since this stand is only for sitting or gentle swinging. Too strong swinging could cause tipping if these instructions are not followed.

When connecting a swing, the swing should be adjusted to be at a safe height that is easy to get on and off.

The stand should be placed on a flat surface free of dangerous objects eg. toys on the ground or other objects that can be tripped over, or nearby objects to bump into. A fall from height or onto a hard surface can result in serious injury to the equipment user; therefore it should be set up and used in a safe manner.

Adult supervision is required.

Important Safety Notes

- Double check that all bolts and connections are tight.
- Supervise any children using the stand: make sure they can get on and off safely, and make sure they use it in a safe manner.

It is important for adults to instruct children NOT to:

- Walk close to, in front of, behind, or between moving items.
- Get on or off a swing while it is in motion.
- Attach additional items to the stand or swing.
- Wear a bicycle or sport helmet while on a swing.
- Stand or jump on a swing or hang from the stand. Distributed weight is best eg. sitting.

Maintaining the Stand

At the beginning of each play season, adults should

- Check all tubing, carabiners and fittings, making sure the setup is strong and undamaged.
- Replace defective parts in accordance with the manufacture's instruction.

At the end of the each play season, or when the weather is bad, adults should:

- The stand is made from weather resistant galvanised steel. The swing that you use with the stand may be more susceptible to weather than the stand (extreme or prolonged UV exposure, dirt or rain), so you may decide to keep the swing under cover when not in use while leaving the stand in place.

Please retain these instructions for future use.