

Safety and Assembly Instructions

IMPORTANT

READ AND FOLLOW ALL SAFETY INFORMATION AND INSTRUCTIONS, KEEP FOR FUTURE REFERENCE



WARNING!

CHOKING HAZARD-SMALL PARTS, NOT FOR CHILDREN UNDER 3 YEARS.

MAXIMUM WEIGHT SHOULD NOT EXCEED 200KG COMBINED USERS WEIGHT.

DO NOT USE WITHOUT ADULT SUPERVISION.

ADULT ASSEMBLY REQUIRED.




ESSENTIAL INFORMATION






- Recommended for children 3+ years
- Do not leave child unattended while in use
- CAUTION: Use only under adult supervision
- Good safety practices should be followed at all times
- Read all instruction before using this product.

Ideally, the swing should be hung over a soft surface such as padding, grass, sand or wood chips. It should not be hung over concrete, asphalt, or other hard surfaces. Distance from ground should not exceed 40cm.

Can be hung on a frame, swing set, beam or tree limb of a diameter of at least 25cm.

Assembling your swing

 <p>Large tubes</p> <p>Small tubes</p> <p>1. The hangout comes disassembled as 6 large tubes, 4 small tubes, canvas and pillow.</p>	 <p>2. Turn the top of the canvas inside out.</p>	 <p>3. Insert the 4 small tubes into the sleeves at the top of the canvas. Connect the pop-tabs so that the tubes form 2 half-circles.</p>
--	---	---

 <p>4. Connect the 2 half-circles. Then flip the canvas right-side-out again</p>	 <p>5. Hang the canvas. If the base is touching the ground, it'll be easier.</p>	 <p>6. Insert the 6 large tubes into the sleeves in the base. Connect them into 2 half-circles. Connect the 2 half-circles as before.</p>
 <p>7. Insert the pillow into the base. This will help to spread the weight across the canvas, and make it softer.</p>	 <p>8. It's ready to be attached to your hangout point.</p>	

Ensuring Safety of the Swing

Clearance distance should be ~1.5m around the swing (the swinging radius can vary depending on the distance from the top of the swing to the hanging point). The swing is not intended for strong swinging, but it's good to keep the area clear anyway.

An adult should check that children can get in and out safely.

A fall onto a hard surface can result in serious injury to the equipment user.

Do not use the equipment until properly installed.

This swing is not to be used in any other manner other than its intended use.

Adult supervision is required.

Adults should verify that the inside and outside of the swing are in safe and working order.

It is important for adults to instruct children to:

- Dress appropriately while using the swing (avoid ponchos, scarves, and other loose-fitting clothing that can potentially get caught)

- Sit toward the center of the swing if using it alone.

It is important for adults to instruct children **NOT to**

- Walk close to, in front of, behind, or between moving objects
- Excessively spin the hangout, in effect, twisting the hanging accessories and material (unless suitable swivel or accessories are installed).
- Get off the sing while it is in motion
- Climb on the swing when it is wet.
- Attach additional items to the swing.

Maintaining the Swing

Cleaning:

- Spot clean only. Use a mild detergent and hand scrub with warm water.

At the beginning of the each play season, adults should:

- Check and tighten hardware if necessary.
- If the swing is hung from a tree branch, then rake and check depth of loose-fill protective surfacing materials (such as mulch or sand) to prevent compaction and to maintain appropriate depth (Min amount ~ 25cm), replace as needed.

Storage:

- Suggested not to leave it outdoors permanently – while it is weather resistant, extended exposure is still not suggested.
- Store the swing in a dry environment, and out of strong UV.