


Safety and Assembly Instructions



WARNING!
SUGGESTED FOR CHILDREN OVER 3 YEARS.
MAXIMUM WEIGHT SHOULD NOT EXCEED 150KG.
DO NOT USE WITHOUT ADULT SUPERVISION.

Assembly Instructions:

1. This swing is pre-assembled, so take the swing out of the box and check whether the material is fine. In the event that the material is not in good condition, stop using immediately.
2. Attach the swing to a strong tree branch or other strong anchor point or frame.

Safety Instructions:

1. Read the instructions carefully before use.
2. Before starting to use the swing, make sure the ring at the top of the swing is safely and securely attached to the hanging point.
3. The swing should be adjusted to be not more than 40cm above the ground.
4. Maximum capacity is 150KG.

6. Do not place anything under the swing. Hanging above a soft surface is preferable, and it should not be above a hard surface like concrete. Put soft padding under the swing if the ground is hard.
7. Do not jump on or off the swing.
8. The swing should be set up by adults, and children under 12 years old should use this swing under supervision.
9. The swing is quite heavy, so it should not be pushed so high that it may hit somebody.
10. Check the swing, hanging points, and attachments carefully. A secure fit is required before using.
11. Take off your shoes before swinging. Keep the swing steadily when getting on and off the swing.
12. Keep these instructions for future reference.

Maintenance Instruction:

1. Swing hooks and metal suspension should be greased regularly. Also check swing hooks and rings for rust points, which could affect their strength. Replace if in any doubt.
2. Check swing ropes for fraying or extreme wear resulting from the twisting of the swing accessories. Replace if in any doubt.
3. The swing can be packed away when not in use, in a dry place. Do not keep it under strong UV or weather for extended periods.