

Instructions for Rectangle Mat Swing



IMPORTANT

READ AND FOLLOW ALL SAFETY INFORMATION AND INSTRUCTIONS, KEEP FOR FUTURE REFERENCE



WARNING!

CHOKING HAZARD-SMALL PARTS, NOT FOR CHILDREN UNDER 3 YEARS.

MAXIMUM WEIGHT SHOULD NOT EXCEED 100KG.

DO NOT USE WITHOUT ADULT SUPERVISION.

ADULT ASSEMBLY REQUIRED.






1-2 adults needed for assembly.

Hanging hardware not included. Ideally, the swing body should be hung over grass, sand, wood chips, or other soft surfaces. It should not be hung over concrete, asphalt, or other hard surfaces. Distance from ground should not exceed 40cm; there are two 8-hooks attached to the ropes to allow for adjustment of the rope length.

Please be sure to examine the ropes regularly to check for wear. If the color of the rope has become pale, frays easily, or gives off a powdery material when rubbed between the fingers, we recommend you replace the rope.

Equipment should be hung in such a way that a distance of at least 2m is clear on either side. Can be hung on an A-frame or swing set or on a suitably strong tree limb.

Assembling your swing

 <p>1. Swing arrives as 4 tubes, 2 hanging ropes, and a mat for assembly.</p>	 <p>2. Put the 2 bent metal tubes through the tabs of the mat first.</p>	 <p>3. Put the other 2 straight metal tube through the webbing and connect the 4 tubes together</p>
 <p>4. Lock the tubes by inserting the bolts from the ropes, and tighten them. It can be easier with 1 person to hold the padding open, while another person inserts the bolts and tightens them.</p>	 <p>5. The height can be adjusted by using the 8-hooks on the ropes. Assembly is finished.</p>	

Ensuring Safety of the Swing

Clearance distance should be about 2m around the swing.

A fall onto a hard surface can result in serious injury to the equipment user.

Do not use the equipment until properly installed.

This swing is not to be used in any other manner other than its intended use.

Adult supervision is required.

Adults should verify that the hanging ropes are secured and cannot be looped back on the swing.

Check the strength of the setup and the surface beneath the swing for softness and hazards.

It is important for adults to instruct children to:

- Dress appropriately while using the swing (avoid ponchos, scarves, and other loose-fitting

clothing that is potentially hazardous, or clothes with hard or sharp pieces that could damage the swing).

- Sit in the center of the swing to keep it properly balanced.
- Avoid swinging empty seats

It is important for adults to instruct children **NOT to**

- Walk close to, in front of, behind, or between moving items
- Twist ropes or loop them over the top support bar since such action may reduce the strength of the rope
- Get off the sing while it is in motion
- Climb on the swing when it is wet.
- Attach additional items to the swing.

Maintaining the Swing

At the beginning of the each play season, adults should:

- Check and tighten hardware if necessary.
- Check all protective coverings on pipes, edges, and corners, Replace if they are loose, cracked, or missing.
- Check all moving parts including swing seat, ropes for wear, rust, or other deterioration, Replace as needed. The hardware used for this swing (binding post, screw, S hook, lock washer, flat washer, and metal ring) can be found at local hardware store.
- Check metal parts for rust, if found, and repaint using a non-lead-based paint meeting the EN71 requirements.
- If the swing is hung from swing set frame, then lubricate all metallic moving parts that are attached by a metal connection.