

Safety and Assembly Instructions



Hanging Pod

WARNING! For ages 3+

Weight Capacity: 80KGS

Removable cushion

Adult supervision required

We hope you enjoy this hanging pod, which you can use indoors or outdoors (just avoid leaving water pooling inside, if it gets wet).



After finishing setup, please make sure the zipper is on the inside of the pod. This will reduce the stresses on the stitching. If the zipper is on the outside, then flip the pod inside out so the zipper is on the inside.

Assembling your swing



1. Remove the pillow from its vacuum sealed bag.



2. Open the zip and put the pillow inside. Close the zip and make sure the zip is on the **inside** of the pod (this is important).



3. Assembly is finished and ready to hang.

Hanging safety instructions

Ideally, the hanging chair should be hung over grass, sand, wood chips, or other soft ground. It should not be hung over concrete, asphalt, or other hard surface. A fall onto a hard surface can result in serious injury to the equipment user. Distance from ground should not be more than 35cm. It is usually hung from a ceiling, beam or strong tree, or from a stand or swing set.

The pod is not intended for strong swinging, but rather for sitting, though you should keep the area around the swing free of dangerous objects anyway eg. toys on the ground or other objects that can be tripped over, or nearby objects to bump into.

Adult supervision is required.

It is important for adults to instruct children to:

- Dress appropriately while using the swing(avoid ponchos, scarves, and other loose fitting clothing that is potentially hazardous)
- Sit in the center, with full weight when swing alone
- Have bare feet or gentle shoes.

It is important for adults to instruct children NOT to:

- Walk close to, in front of, behind, or between moving items.
- Get on or off the swing while it is in motion.
- Attach additional items to the swing.
- Wear a bicycle or sport helmet while on the swing.

Maintaining the Swing

At the beginning of each play season, adults should

- Check all fabric sewing parts, make sure it is strong enough.
- Replace defective parts in accordance with the manufacture's instruction.

At the end of the each play season, or when the weather is bad, adults should:

- Remove the swing from its outdoor location.
- Store the swing in a dry environment.

Please retain these instructions for future use.