


# Safety and Assembly Instructions

## Tripod Stand



### **WARNING!**


Weight Capacity: 80KGS

*(Though if the swing capacity is lower,  
then you follow that limit instead)*

Height Adjustable By Chain & Carabiner

We hope you enjoy this tripod stand, matched with suitable swing.

# Stand Diagram



Spare Parts List									
Item	A	B	C	D	E	F	G	H	I
Name	Upper-frame	Chain	Carabiner	Screw	Spring Washer	Rope	Tube-1	Tube-2	Tube-3
Quantity (PCS)	1	1	1	36	36	1	3	3	3


# Assembling your stand



1. Remove the tubes from the carton.



2. Collect the accessories.



Spare Parts List									
Name	A	B	C	D	E	F	G	H	I
Quantity (PCS)	1	1	1	80	80	1	1	1	1

3. Refer to the stand diagram (previous page) before proceeding.



4. Start from the top. Bolt piece A to the G pieces.

Then G's are bolted to H's.

Check that the ropes on the I pieces are not tangled.

Then H's are bolted to I's.



5. Once in position and with legs fully extended at the right angles - attach the pegs or sandbags over the ropes near to each leg.



6. Attach the chain to the top O-ring. So it'll be O-ring, carabiner, chain, carabiner, swing.



7. Attach your swing to the bottom carabiner.

You can latch the carabiner to a higher link on the chain if you want to move the swing higher.

Setting it up lower will give more clearance from the poles.



8. Stand assembly is finished.



9. If using it indoors, you might want to add something like leg protectors (not included) below the legs to protect your floor.

# Safety instructions

The stand should be placed on a flat surface free of dangerous objects (toys on the ground or other objects that can be tripped over), and is designed for gentle-moderate swinging. Too strong swinging would cause you to bump into the poles.

When connecting a swing, the chain and carabiners should be adjusted so the swing is at a safe height that is easy to get on and off.

Adult supervision is required.

## Important Safety Notes

- Double check that all bolts and connections are tight.
- Supervise any children using the stand with a swing or chair, particularly: make sure they can get in and out safely, and make sure they use it appropriately.

## It is important for adults to instruct children NOT to:

- Walk close to, in front of, behind, or between moving items.
- Get on or off the swing while it is in motion.
- Attach additional items to the stand or swing.
- Wear a bicycle or sport helmet while on the swing.
- Stand on a swing or hang from the stand. Distributed weight is best eg. sitting or lying.

## Maintaining the Stand

At the beginning of each play season, adults should

- Check all tubing, carabiners and fittings, making sure the setup is strong and undamaged.
- Replace defective parts in accordance with the manufacture's instruction.

At the end of each play season, or when the weather is bad, adults should:

- Store the swing in a dry environment out of the sun, especially when leaving it for prolonged periods. The stand is weather resistant from powder coating. Avoid scratching the powder coating (paint), which would reduce the weather resistance.

**Please retain these instructions for future use.**