# **Safety and Assembly Instructions**

### IMPORTANT

READ AND FOLLOW ALL SAFETY INFORMATION AND INSTRUCTIONS, KEEP FOR FUTRUE REFERENCE

### **ESSENTIAL INFORMATION**

- For users 3+ years old.
- CAUTION: Use only under adult supervision. Do not leave child unattended while in use.
- Good safety practices should be followed at all times
- Read all instruction before using this product.
- 1-2 adults needed for assembly.
- Maximum weight capacity: 100kg

Hanging hardware not included. Ideally, the swing body should be hung over

grass, sand, wood chips, or other soft surfaces. It should not be hung over concrete, asphalt, or other hard surfaces. Distance from ground should not exceed 40cm.

Please be sure to examine the material regularly to check for wear. Material will, in time, degrade. Equipment should be hung in such a way that a distance of at least 1.5m is clear on either side. Can be hung on a swing set of suitable height (about 2.1m or higher hanging point), beam or tree limb of a diameter of at least 25cm.

## Assembling your swing

		- Alt
1. The open hangout arrives	2. Lay the canvas out (note the	
with the canvas, rings & pillow	zipper at the bottom).	
separate.		3. Insert each tube into the
		zipper, locking the pop-locks as
		you go around.
4. Once all tubes are connected		
as a circle, you can close the zipper.		
	5. Add the pillow, and attach the	
	swing to your suitable hanging	
	point.	

### **Safety Notes**

Clearance distance should be 1.5m around the swing. A fall onto a hard surface can result in serious injury to the equipment user. Do not use the equipment until properly installed. Adult supervision is required.

It is important for adults to instruct children to:

- Dress appropriately while using the swing (avoid ponchos, scarves, and other loose-fitting clothing that is potentially hazardous)

- Sit in the center of the swing if sitting on it alone.

- Use it in a safe manner, eg. sitting/laying being safer than standing/jumping/hanging.

It is important for adults to instruct children **NOT TO:** 

- Insert body parts between the supporting ropes, or to get entangled (particularly the head). <u>This is of particular note for supervision.</u>

- Walk in front of, behind, or between moving objects.

- Get off the swing while it is in motion

- Climb on the swing when it is wet.

- Attach additional items to the swing.

### Maintaining the Swing

While the material is weather resistant Oxford polyester, mildew is still a possibility with light colours like beige, particularly if left moist and/or dirty for long periods.

- Avoid prolonged moisture and strong UV.

- Avoid leaving dirt and organic matter on the material for prolonged periods.

- First steps: brush off with a soft, dry brush.

- If needed: hand wash with gentle detergent. Flush with clean water. Hang to drip dry.